

Hardware Installation

- 1 Power off the router.
- 2 Connect the 3G/3.5G USB modem (with the SIM card inside) to the USB mini-B plug located on the top panel of the router.




- 3 Connect the RJ45 cable from the router's LAN port to your computer.
- 4 Connect one end of the power adapter to the router's PWR port and the other end to the electrical wall outlet.



- 5 Power on the router.

Configuration

- 1 To access the web-based utility, type "http://192.168.0.1" in your web browser and press "Enter".



- 2 When prompted to login, type "admin" in both the User name and Password fields, and then click on the "OK" button.



NEXT PAGE >>

- 3 In the Basic > USB Modem webpage, depending on your mobile network operator, you may need to enter the following information:
- User Name
 - Password
 - APN Name
 - PIN Code

APN Configuration

User Name :

Password :

Dial Number :

APN Name :

PDP Type : IP PPP

PDP Address : . . .

PIN Code :

- 4 Leave other settings as defaults unless specified by your mobile network operator (Note: some settings are empty by default).
- 5 If you have a flat rate Internet access and you want the router to automatically connect to the Internet every time it is powered on, select "Enable" for "Auto Connect".

Connection Settings

Connection Status : Disconnected

Auto Connect : Enable Disable

Disconnect after idle for : min (0 - Never Disconnect)

- 6 Click on the "Submit" button to save the changes.
- 7 To change the Network Name (SSID) for your wireless network, go to the Basic > Wireless page.
- 8 The default SSID is "umbra220". You may want to change the SSID if:
- You want to use your own preferred name.
 - Another wireless network operating in your area has already been using the default name.

Wireless Settings

Network Name (SSID) :

Channel :

Security Mode :

- 9 You are encouraged to turn on the security for your wireless network. To do that, please refer to Wireless Settings section in the User Guide.
- 10 If you do change any settings on this page, please click on the "Submit" button to save the changes.
- 11 Reset the router by powering it off and then power it on again.
- 12 Congratulations - you have successfully configured your router!

Connect/Disconnect USB Modem

- 1 It is safe to connect/disconnect the USB modem even when the router is powered on.
- 2 After disconnecting the USB modem, you are recommended to wait for at least 5 seconds before reconnecting it to the router.